

# **Easy Setup Instructions**


This outboard is shipped **without oil** in the engine.


You must **add oil** before use.


BF8D • BFP8D BF9.9D • BFP9.9D BF15D • BFP15D

BF20D • BFP20D



















# Starting The Engine & Break-in

Refer to the OPERATION section of the Owner's Manual. Follow the instructions for starting the engine and performing the break-in procedure for the outboard motor.

Proper break-in operation allows the moving parts to wear in smoothly for best performance and long service life. Avoid continuous operation at a steady speed.

### Registering Your Outboard Motor

Register your outboard motor to receive important service information and updates.

Visit marine.honda.com and click on Service & Support, then **Product Registration**.

## Have a question or a problem?

Most questions or concerns can be answered by reading the Owner's Manual or contacting the retailer where you purchased your Honda outboard motor.

#### Where is a dealer near me?

You can find the closest Authorized Honda Marine Dealer to you by visiting marine.honda.com and clicking on **Find A Dealer**.