



1. Attach the hose to the pump by twisting the black "cap" onto the threaded port of the hand pump. Choose the hooked adapter for recessed valves (photo 3). Choose the flat adapter for white & black valves (photo 4).

2. Set pump to "Double Action."

3. Insert adapter into recessed valve. Twist to the right to lock in place.

4. Pull handle up towards chest just shy of the pumps maximum extension. Press down completely. Repeat at a comfortable pace until significant resistance is felt.

5. Switch to "Single Action" to complete inflation until the gauge reads the recommended pressure.



Rounded Tubes (e.g. Explorer, FastTrack, PaddleSki)





Drop-Stitch Chambers (e.g. FastCat, FishSkiff)

Drop-Stitch Chambers (e.g. Explorer, FastTrack, PaddleSki Floors)

## \*\*\*Always Consult Boat Manual For Correct Pressure\*\*\*

3-Year Warranty Against Manufacturer Defects Visit www.SeaEagle.com/Warranty • Staff@SeaEagle.com or Call 1-800-748-8066



